

FIG. 3A




FIG. 4






FIG. 5




<u>2B</u> FIG. 6 5BG KB1 PRE-CHARGE MODE LOAD






(1): PRE-CHARGE

2 : 42V DRIVE ENGINE START
3 : 42V CHARGE (START ERECTRIC POWER)
4 : 12V CHARGE (VEHICLE LOAD ERECTRIC POWER)
5 : DISCHARGE





9/13

(1): PRE-CHARGE(2): 42V DRIVE ENGINE START(3): 42V CHARGE(4): 12V CHARGE(5): DISCHARGE

FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14

